

 INSTALLATION GUIDE


**OBEX**  **CORTEX<sup>®</sup>FR**

0560FR

# Interface Sealing Membrane

Class B

 **OBEX<sup>®</sup>**



## Important Notes


- » Before application prime all Porous surfaces with OBEX CORTEX 0787FR Class B Non-Flammable Surface Primer.
- » The required overlap between members and porous materials (concrete, brick) is 100mm.
- » For non-porous materials, we recommend a 50mm bond width, and an absolute minimum of 30mm.
- » Make sure to adequately cap off all edges of the membrane with paste, leaving no exposed edges.
- » The rolls may invariably contain joins. These should be overlapped and bonded by a minimum of 50mm.



1

Ensure the window surround is complete and ready to receive the ISM.


Mark up the substrate to ensure the correct bond widths are achieved. The required bond widths are; 100mm onto porous surfaces (concrete etc) and a minimum of 20-30mm onto non-porous surfaces.



2


Apply OBEX CORTEX 0787FR Primer to porous surfaces. Ensure a full coverage over the bonding area. Porous surfaces include cement board, calcium silicate board, concrete etc.





3


Measure the length of the section and cut the membrane to the correct length. Remember to allow approx. 100mm overlap past the corners of the glazing unit.



4


Remove the release liner from one side of the membrane.





5

Bond the membrane in position starting at the window frame. Once positioned and bonded, the corner laps can be cut and folded into position.



6

Remove the release liner from the second half of the membrane.





7


Bond the second half of the membrane into position and firmly roll with a roller.



8

Ensure all surfaces are firmly rolled to ensure maximum bond strength is achieved.






9

Apply a small section of OBEX CORTEX 0771FR Class B Paste Adhesive to the corner area as shown. (both sides of the window frame)





10


Repeat steps 3-9 for each side of the window frame.



11

Cut the corner laps as shown and bond in place.






12


Remove the release liner from the second half of the membrane and bond in place. Ensure all surfaces are firmly rolled for maximum bond strength.





13

Ensure a small amount of OBEX CORTEX 0771FR Class B Paste Adhesive is applied in the corner areas as shown.



14

Repeat the same procedure for the Head membrane.





15

Cut and fold the corner laps into position.





16

Ensure all membrane surfaces are firmly rolled with a roller for maximum adhesion levels.



17


Apply a bead of OBEX CORTEX 0771FR Class B Paste Adhesive around all edges/joints/overlaps of the OBEX CORTEX 0560FR Class B Fully Adhesive Backed ISM.





Tool-off the bead of adhesive with a spreader to ensure all edges/joints/overlaps are fully sealed.





19

This is how ISM's around windows should look once complete.



**OBEX Protection Ltd.** Unit 12 Horn Hill Road, Nunnery Park, Nunnery Way, Worcester, WR4 0SX.

**Call:** +44 (0) 1905 337800 | **Email:** [sales@obexuk.com](mailto:sales@obexuk.com) | **Visit:** [www.obexuk.com](http://www.obexuk.com)

© Copyright 2022 OBEX. All rights reserved. Company Registration No. 09157067, VAT No: 868 7649 48