

## 0786 Spray Primer

# Technical Data Sheet

Version 01.01.01 Updated 14/11/25

## **Product Description**

OBEX CORTEX 0786 Spray Primer is a is a solvent based primer based on synthetic rubber and resins, and is specifically designed for use with all self-primer membranes and vapour barriers. It can be applied to metallic substrates, bituminous materials, wood based materials, and insulation boards. 0786 dries within 1-2 minutes and can be walked on without transfer to the soles of safety tools.

#### Technical Data

Base	Synthetic Rubber & resins
Appearance	Black
Temperature resistance	-30°C to 90°C
Storage	5-25°C
Shelf life	18 months
VOC Content	574 grams per litre
Solids	35%
Solvent System	Non-Chlorinated

## Directions for use

For best results, the temperature of the primer and the surfaces being bonded should be between 16  $^{\circ}$ C - 27  $^{\circ}$ C.

Use with adequate ventilation. When possible we recommend shaking the canister well before using.

Prior to use, check compatibility by spraying a small test patch of the primer on the substrate. This product may degrade some substrates.

- 1. Make sure that surfaces are clean, dry and free from dirt, dust, oil, loose paint, wax or grease, etc.
- Spray about 10-20 cm (4" 8") away at a 90 degree angle to the surface, with 50% overlaps applying a uniform, even coat of primer to obtain 80% to 100% coverage of the surface. If necessary, spray another coat of primer in areas that appear to need more primer.

- 3. Allow 2 minutes for the primer to tack off until no primer transfers to the knuckle when touched.
- 4. Adhere surfaces and press together with adequate pressure. A roller is recommended to apply a uniform pressure to achieve maximum strength. Allow 24 hours for the primer to fully cure.

# Handling & Storage

- Consult Material Safety Data Sheet prior to use.
- DO NOT store at temperatures over 50°C.
- Avoid exposure to direct sunlight.
- DO NOT store directly on concrete floor.
- For optimum performance, store at 18°C during use, but must always be above 10°C.
- Always test product to determine suitability for your particular application prior to use in production.

